

EMP P/N - 11893

Polaris Ranger (with Pro-Fit Cage) Cab Back/Dust Stopper Made from Hard Coated Polycarbonate

Fits:

2013-18 Ranger XP900 and XP900 Crew
2015-18 Full Size Ranger 570 w/Pro-Fit cage
2015 Ranger 570 Crew
2016 Ranger XP570
2016-17 Ranger Diesel
2017 Ranger XP1000 and XP1000 Crew
These models are 60" wide and have a Pro-Fit Cage.

Includes:

1. (1) Hard Coated Polycarbonate Cab Back
2. (5) 1/4" x 1-1/4" Black Fender Washer
3. (2) 1/4-20 x 1" Black Flange Bolt
4. (3) 1/4-20 Nyloc Nut
5. (3) 1/4-20 x 3/4" Min. Self Tapping Bolt (black)
6. (2) 1/8" x 1" wide x 21" Adhesive Backed Foam
7. (2) 1/8" x 1" wide x 57" Adhesive Backed Foam
8. (1) 6" Long "Hook & Loop" Strip
9. EMP® Logo Decal

Installation:

1. Stick foam to all four sides of the cab back (see picture). This will seal your back.
2. Stick the Hook & Loop to the center of the top. This will keep the top from rattling.
3. Attach the top with the two bolts, large washers, and nuts. The large washers go on the outside. You will want to stick the Hook & Loop to the top too. In other words, peel back the tape on the Hook & Loop.
4. Attach the bottom with the Self Drilling/Tapping screws. You will need to use a drill gun for this. The center hole will be drilled at the same time.
5. Your installation is complete.

