

EMP P/N - 11894

Polaris Ranger 2-Piece Top

Fits: 2013-18 Ranger (60" Wide w/Pro-Fit Cage)
2015-18 Mid-Size Ranger (50" Wide w/Pro-Fit Cage)

Includes:

1. (1) Top (two halves).
2. (1) Rear Support –(11894-01)Long L-Shaped Bracket
3. (10) 1-1/4" Black Fender Washer
4. (12) 1/4" Nyloc Nut
5. (10) 1/4-20 x 1-1/4" Black Phillips Pan Head Screw
6. (22) 1/4" Washer– Clear Zinc Plated
7. (2) 1/4-20 x 3/4" Flange Head Bolt
8. (1) 1/8" x 1" wide x 6" long adhesive backed gasket.
9. (8) 5/16" Plastic Rivet
10. EMP® Logo Decal

Installation:

1. Install the rear support using the two 3/4" long bolts, nuts, and washers (see picture).
2. Install the passenger side first. You will want to drill the outer rear hole first, then the front outer hole using a 1/4" drill bit. You will use an existing hole in the front of the cage.
3. Put a 1-1/4" screw in the rear holes the large washer will go on top.
4. Bolt the front passenger side in place. Note: you will want to use (5) washers between the top and the cage on the outer holes. This will space up the ends a little about 3/8".
5. Measure the distance between the front and back and mark with a Marker. NOTE: You will want to make sure that the front is not pushed in too far. Take your time and measure twice.
6. Clean the areas that will be taped. Stick the drivers side on top of the passenger side. NOTE: The longer the tape sticks the stronger it will become. So make sure you have it in the correct location. The small holes are for optional screws if you choose to bolt the sides together. It is really not necessary.
7. The gasket material can be stuck to the center of the front of the cage under the top. This will keep the top from touching your cage in the middle.
8. Drill the two outer holes in the drivers side. Put screws in the holes.
9. Lastly, you can use the Plastic Rivets to hold the two halves in place. This is optional and the small holes in the top can be used as a template. Use a 5/16" drill bit. Check to see what you are drilling through. In other words, make sure you do not have the top positioned so you drill through your cage tubes.
10. Your installation is complete.

