



POLARIS RANGER GRILLE

2012-2013 POLARIS® RANGER

GRILLE INSTALLATION INSTRUCTIONS
10" SR-SERIES™



KIT INCLUDES

(1) Mounting Bracket

IMPORTANT

It is strongly recommended that this product be installed by a professional.

Installation of this product requires cutting of your factory installed grille. Your factory grille will be unusable after it has been cut.

This product may have more surface area than your factory grille. It may reduce airflow. Reduction in airflow can potentially lead to overheating or other mechanical issues.

Always disconnect battery before servicing any fuses or electrical system.



INSTALLATION INSTRUCTIONS

1. Remove the existing lower grille by unscrewing bolts on either side.
2. Secure Rigid Industries® 10" SR-Series™ light in bracket using mount hardware provided with the light. The ¼" threaded studs on the sides of the light will slide into slots on the bracket. Don't fully tighten nuts at this time – you will want to adjust the light angle after it is installed on the vehicle.
3. Mount the new grille with the light installed where the lower grille was removed. Secure with the original bolts.
4. Wire your light(s) using the wire harness and switch provided. Take care to avoid any sharp or abrasive surfaces when routing the wire.
5. Once your lights are wired, position your vehicle on a flat surface, facing a wall. Adjust aim on your lights so that the beam is pointing in the vertical direction you want.

Your installation is now complete.

Welcome to the Rigid Nation!

FOLLOW US ON FACEBOOK AT
[facebook.com/RigidIndustries](https://www.facebook.com/RigidIndustries)

779 N Colorado St, Gilbert, AZ 85233 • 855-760-5337 • www.RigidIndustries.com

12/2013 IS-40340

