

Installation Instructions

UTV Folding Windshields – All Applications



Contact Information:

Phone: 877-847-1558

Email: QuadBoss@QuadBoss.com

Before you begin, read these instructions carefully and check to see all parts and tools are accounted for. Please retain these installation instructions for future reference.



Image # 1

Installation is universal for all UTV application. Polaris RZR 1000 shown for illustration purposes. "Up" Position

Kit Components

1. Full windshield	Qty. 1
2. Clamp	Qty. 4
3. 7/16" Phillips Head Screw	Qty. 4
4. 7/16" Flat Washer	Qty. 4
5. 7/16" Lock- Nut	Qty. 4
6. Instruction Sheet	Qty. 1

Tools Required

Phillips Head Screw Driver

7/16" Wrench

Installation Instructions

- 1) **Prepare machine – Make sure vehicle is clean and free of all debris**
- 2) **Install clamps – Place two clamps on the forward most portion of the cab frame tubing. Make sure the flat portion of the clamp is towards the front of the vehicle. (See image #2)**
- 3) **Align the windshield – Place the windshield into position so that it is centered on the front of the cab frame. Be sure to center the windshield to the frame and that it follows the mating hood profile properly.**
- 4) **Attach shield – Using the hardware kit provided, secure the windshield to the cab frame.**
- 5) **When in the "UP" position, secure upper windshield in place by wrapping rubber strap around roll cage and fitting slot over ball stud in windshield. (See image # 1)**
- 6) **When in the "DOWN" position, secure windshield by folding on top of hood and using the rubber strap and attaching it to the ball stud bracket. (See image # 3)**



Image #2 Clamp installation detail

Cleaning Instructions:

1. Rinse with water to remove large dirt particles from windshield.
2. Use warm soapy water and soft cloth to remove remaining dirt
3. Rinse thoroughly and air dry
4. Use plastic cleaner



Image # 3 – "Down" Position