

POLARIS 900 ROOF INSTALL INSTRUCTIONS

NOTE: It is recommended that bolts remain hand tight until all bolts are installed.

1. Install the rear dust cover (item 3) to the upper rear portion of the roll cage. Using provided bolts (B3), align the holes of the rear dust cover to the matching holes on the sheet metal portion of the roll cage and install bolts with nuts and flat washers. At this time it is acceptable to tighten all bolts, this piece is separate from the rest of the assembly.
 2. Carefully place both roof sections (items 1, 2) on top of the roll cage, overlapping the rear section (item 2) with the front section (item 1).
 3. Using the provided bolts (B2), align the front three holes of front section (item 1) with the matching holes in the front, top sheet metal portion of the roll cage and install bolts with flat washers and nuts.
 4. Using provided bolts (B1), align the center holes of both roof panels with the matching holes of the center mounting brackets (item 4) and install bolts. These brackets will sit on top of the center cross brace of the roll cage.
 5. Using the provided bolts (B1), attach the rear mounting bracket (item 6) to the rear two holes of roof panel (item 2).
 6. Using provided bolts (B1), align the center holes of both roof panels with the matching holes of the center mounting brackets (item 4) and install bolts. These brackets will sit on top of the center cross brace of the roll cage.
 7. Using the provided bolts (B1), align holes from the center mounting bracket (item 4) with the holes in the center mounting bracket clamp (item 5) and install bolts. These bracket clamps will secure on the center cross brace of the roll cage.
 8. Once **all** bolts are installed, adjust and tighten all bolts.
 9. Enjoy your new Bad Dawg roof!
-

Hardware List:

B1. ¼"-20 x 1" BUTTON HEAD BOLT	X 18
B2. ¼"-20 x ¾" BUTTON HEAD BOLT with nylock nut and flat washer	X 3
B3. 3/16" x ¾" BUTTON HEAD BOLT with nylock nut and flat washer	X 4