

Polaris Ranger 570-6 / 800 Crew Steel Roof



Product Instructions | Part No: 29160

Application: Polaris Ranger Crew 570-6 / 800, verify accessory fitment at Kolpin.com.

Before You Begin: Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

Note: If any hardware is missing, do not return to the store. Call us to help, Toll Free 1-877-956-5746.

Note: Two people are required to install this Roof Kit.


Items marked (*) are included in Hardware Kit PN 29161.

Tools Required:

- Socket Set, Metric
- Wrench Set, Metric
- Utility Knife/Cutting Tool
- Torx Bit Set
- Torque Wrench

This Kit includes:

Item	Qty	Part Description
1	1	RGR Crew Front Roof Panel
2	1	RGR Crew Rear Roof Panel
3*	16	Flat Washer, Zinc Plated, M6
4*	16	Button Screw, Zinc Plated, M6-1.0 x 25mm LG
5*	16	Flange Locknut, Zinc Plated, M6-1.0
6*	1	Rear Foam Strip 55" (1400mm)
7*	2	Side Rear Foam Strip 30.12" (765mm)
8*	2	Side Front Foam Strip 22.75" (578mm)
9*	1	Rubber Overlap Trim Seal
10*	10	Clamp, Painted, 1.75" Diameter
11*	1	Front Foam Strip 38.25" (972mm)
12	1	Instruction Guide (not shown)



Kolpin Outdoors, Inc. | 9955 59th Ave N | Plymouth, MN 55442




(877) 956-5746 or (763) 478-5800 | www.kolpin.com | customerservice@kolpin.com

Assembly Time: Approximately 30 minutes

Important: Your Kolpin Steel Roof Kit is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown. For better cab assembly procedure, install kits in the following order: front window, rear window, and roof.




Installation Instructions:

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Being careful to not scratch painted surfaces, place the front steel roof panel (item #1) onto rear steel roof panel (item #2). Fasten panels together by using four M6 screws (item #4) and four M6 washers (item #3) inserting through the outer holes at the overlapping seam. Loosely secure with M6 locknuts (item #5) on underside roof surface. (See illustrations 1-1 and 1-2). **Note, place rubber seal (item #9) in between the two roof panels as shown. Do not tighten hardware at this step since adjustments may be required later.**
3. Clean lower surface of front roof (item #1) and rear roof (item #2) as required, then apply the foam strips (items #6, #7, #8, #11) as shown. Trim seals as required. (See illustration 1-3). **Note: You can position roof assembly on cab frame, aligning rear edge with rear cab, then mark with tape or pencil where the cab frame tubes match with surface of roof. The alignment marks help locate where the foam strips will be applied.**



Installation Instructions (Continued):


4. Place roof assembly on the top of the vehicle cab frame as shown. (See illustrations 1-4 and 1-5).
5. From the top surface, secure front of roof using the M6 screws (item #4) and M6 flat washers (item #3) as shown. (See illustration 1-6). **Note: Do not tighten hardware at this step since adjustments may be required later.**
6. From underneath roof, place clamps (item #10) around cab frame tubing and loosely fasten front screws with M6 locknuts (item #5) as shown. (See illustration 1-7). **Note: Do not tighten hardware at this step since adjustments may be required later.**
7. Secure the rear of the roof to the vehicle using the M6 screws (item #4) and M6 flat washers (item #3) as shown. (See illustration 1-8). **Note: Do not tighten hardware at this step since adjustments may be required later.**



Installation Instructions (Continued):

8. From underneath roof, place clamps (item #10) around rear cab frame tubing and loosely fasten rear screws with M6 locknuts (item #5) as shown. (See illustrations 1-3 and 1-9). **Note: Do not tighten hardware at this step since adjustments may be required later.**
9. From underneath roof at rear cab frame gusset tab, loosely fasten the two lower rear screws with M6 locknuts (item #5) as shown. (See illustration 1-9).
10. Tighten all hardware to specification.

 = T
6MM FASTENER TORQUE: 7 ft. lbs. (9.5 Nm)



Use and Care Information:

- Check the accessory mounts frequently and retighten hardware if necessary.
- Replace this accessory with a new one if it is damaged.
- Never use petroleum solvents such as gasoline, thinner, benzene, acid or alkaline cleaners.

For additional assistance, please contact Kolpin customer service department at (877) 956-5746 or (763) 478-5800 or email customerservice@kolpin.com

One Year Limited Warranty

For the period of one (1) year from the purchase date, Kolpin will replace for the original purchaser, free of charge, any part or parts found upon examination by Kolpin to be defective in material, workmanship, or both.

All transportation costs incurred submitting product to Kolpin for warranty consideration must be borne by the purchaser. If Kolpin determines that the product must be returned to the factory for credit, please call 1-877-956-5746 for a Return Merchandise Authorization (RMA) number and shipping instructions.

This warranty does not apply to parts that have been damaged by accident, alteration, abuse, improper maintenance, normal wear, or other causes beyond the manufacturer's control. In order to protect you and your ATV, certain parts of the accessory system and/or hardware are designed to fail when the equipment is over-stressed. Parts that are lost due to loosening and improper maintenance are not covered under warranty. This warranty does not cover removal or reinstallation labor fees of the roof system and related components.

Peripheral products such as engines, electric motors, and actuators may carry an original manufacturer's warranty. Most hardware is general in nature and is easily obtained locally. Be sure to replace with minimum metric class 8.8 specification.